


HOME DECORATORS COLLECTION

SK17755A LOFTEN CONSOLE 30"Hx45"Wx15"D

INV#16376






ASSEMBLY INSTRUCTIONS

Made In China




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present, If any parts are missing or damaged, phone, fax, or mail to our Customer service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast,easy and correct assembly.

PARTS LIST		
A  TOP PANEL-1PC	B  BOTTOM PANEL-1PC	C  FIXED PANEL-2PCS
D  POST(1)-2PCS	E  POST(2)-2PCS	
a  Ø1/4"*2"L BOLT-8PCS	b  Ø1/4"*1-1/4"L BOLT-8PCS	c  SPRING WASHER-12PCS
d  WASHER-12PCS		


NOTE:THE SURFACE WITH THE STICKER IS THE BACK SIDE

FIG 1




- ATTACH THE POSTS(D) & (E) TO THE TOP PANEL(A) USING THE 2" L BOLT(a), WASHER(d) AND SPRING WASHER(c) AS SHOWN.

FIG 2




- ATTACH FIXED PANELS(C) TO THE POSTS(D) & (E) USING THE 1-1/4"L BOLT(b),WASHER(d) AND SPRING WASHER(c) AS SHOWN.

FIG 3



- ATTACH THE POSTS(D) & (E) TO THE TOP PANEL(A) USING THE 2" L BOLT(a), WASHER(d) AND SPRING WASHER(c) AS SHOWN.
- ATTACH THE POSTS(D) & (E) TO FIXED PANELS(C) USING THE 1-1/4" L BOLT(b), WASHER(d) AND SPRING WASHER(c) AS SHOWN.

FIG 4



- ATTACH BOTTOM PANEL(B) TO THE POSTS(D) & (E) USING THE 2" L BOLT(a) AS SHOWN.